


4K Time Lapse Camera




QUICK USER GUIDE

To access the electronic version of the guide, scan the QR code with your smartphone or tablet.




THE CAMERA BODY



- 1 Power Button
- 2 Lens
- 3 UV Filter
- 4 Filter Mount
- 5 Focus Ring

- 6 Mic
- 7 Silicone Cover
- 8 USB-C Port
- 9 2.5mm Digital I / O Socket



- 10 Charging Indicator
- Wi-Fi IndicatorOperation Indicator
- 13 1/4"-20 Tripod Mount
- 14 Camera QR Code

- 15 Battery / Memory Card Door
- 16 Battery / Memory Card Door Latch
- 17 Battery Latch
- 18 MicroSD Card Slot
 - 19 Battery Compartment

BATTERY

Inserting the Battery

7 Pull down the door latch until the battery door pops open.





2 Align the battery so that the "ATLI" logos are facing the same direction as the logo on the back of the camera case.

3 Use the battery to push down the yellow latch until it is fully retracted, allowing space for the battery to be inserted into the battery compartment.



4 Slide the battery in until the yellow latch clicks, locking the battery in place.

Removing the Battery

- **1** Turn off the camera, then pull down the door latch to open the Battery / Memory Card Door.
- **2** Press the yellow latch to release the battery. Then, pull the battery tab to slide the battery out of the compartment.



MEMORY CARD



Inserting the Memory Card

- 1 Open the Battery / Memory Card door.
 - 2 Orient the card so that the metal contacts are facing toward the front side of the camera and the card cutout is facing down.
 - 3 Slide in the memory card until it clicks.

Memory Card Requirements

- Type: microSD
- Capacity: Support max 512GB
- Speed Class: U3 / V30
- Format- evEAT

Removing the Memory Card

To remove the memory card, press the card in and then release slowly.

The card will then eject out a little and can be removed by hand.

CHARGING



- 1 Gently open the cover to access the charging port.
- 2 Use a USB power source with a minimum rating of 5V@1A-3A to charge the

INSTALLING THE ATLI CAM+ APP

Install the ATLI Cam+ app before using the camera.



Scan the QR code on the left, or search for "ATLI Cam+" on the App Store (iOS) or Google Play (Android).





CAMERA REGISTRATION



- 7 Open the ATLI Cam+ app and tap the camera icon to access the camera list. Then click [Add Camera].
- **2** Press the power button to turn on the camera. The camera beeps when turned on.
- **3** Scan the QR code located at the bottom of the camera to proceed.

ATLI CAM+ APP FEATURES



Once connected, the ATLI Cam+ app displays a live view from the camera.


For detailed instructions, scan the QR code on the left to read the X10 In-App Control Instruction Manual.

MANUAL FOCUS

This camera has a manual focus feature to help you capture sharp images.

Subjects Beyond 2 Meters

Turn the focus ring to the preset position until you feel a click, indicating it's locked in place.



Subjects Between 12 CM and 2 Meters

- 7 Slowly adjust the focus ring while observing the live view on the app screen until the image is sharp and clear.
- 2 For precise focus, use the 4x Zoom feature by tapping the Zoom ⊙, selecting the desired area to zoom in for details



UV FILTER (52mm)


To remove the UV filter from the lens, hold the edge of the filter and twist counter-clockwise until it comes loose



ADD-ON FILTER

This product is designed to accommodate standard 52mm filters, allowing for enhanced functionality of the camera to align with artistic vision and adapt to various shooting conditions.

- $\mbox{\ref{T}}$ Securely attach an add-on filter by rotating it clockwise onto the UV filter or the focus ring.
- 2 Additional filters can be layered on top as needed.



STATUS INDICATORS

The camera features three essential status indicators-

Charging: Displays battery level and power status.

Charging: Displays battery level and power status

Wi-Fi: Indicates mode and Wi-Fi connectivity. **Operation**: Reflects camera's operational status.

Indicator	Color	Status
Charging 4	Green Breathing	Charging
	Green Steady	Fu ll y Charged
	Red Blinking	Battery ≤20%
Wi-Fi	Yellow Steady	Ready for Direct Connection
	Green Steady	Connected to WLAN
	Green Blinking	Attempting to Connect
Operation	Yellow Steady	Booting
	Green Steady	Ready to Connect
	Green Blinking	Recording / Shooting
	Red Blinking	Sleeping
	Green / Red / Yellow Blinking	Upgrading

ATLI X10 QUICK USER GUIDE

WARRANTY

This product is covered by a one-year warranty from ATLI, effective from the date of purchase

Coverage

This warranty covers repairs or replacements for defects in materials and workmanship under normal operating conditions.

It does not cover damages caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Accessing Warranty Service

To access warranty service, please contact us via email to report any issues and obtain authorization beforehand.

Email: service@atliview.com

ATLI X10 QUICK USER GUIDE

ALL XIV QUICK OSER GOIDE			
SPECIFICATIONS			
General			
Dimensions (W*H*D)	86*60*67.5mm		
Weight	210g (With Battery)		
Weatherproof	IP64		
Memory Card	Support max. 512GB microSD Card		
Camera			
Sensor	1/1.8" OMNIVISION® CMOS		
Pixel Size	2μm		
Lens	6 Elements Aspherical Lens		
FOV	74°		
Focal Length	6mm		
ISO Range	100 ~ 3200		
Shutter Speed	1/20K ~ 30seconds		
White Balance	2000 ~ 10000		
Focus Method	Manual Focus		
Focus Range	12cm ~ ∞		
Exposure Metering	Center-Weighted		
	Resolution: 3840*2160@30FPS 1920*1080@30FPS		
Time of the state of	Output: Video, JPG, Video+JPG		
Time Lapse Mode —	Interval: 1second ~ 24 hours		
_	Duration: Custom / Infinity		
	Schedule: Max.4 Slots per Day		
Photo Mode	Resolution: 3840*2160, 1920*1080		
Video Mode	Resolution: 3840*2160@30FPS 1920*1080@30FPS		

Photo Format	JPEG	
Video Format	MP4	
Video Encoding	H.264	
Battery		
Туре	Rechargeable Li-ion	
Capacity	4400mAh	
Voltage	3.8V	
Limited Voltage	4.35V	
Charging Temperature	5°C ~ 45°C (32°F ~ 113°F)	
Operating Temperature	-10°C ~ 50°C (14°F ~ 122°F)	
Connectivity		
Wi-Fi Protocol	IEEE 802.11 a/b/g/n/ac	
Bluetooth	5.0	
Interface / Control		
Language	简体中文 / 繁体中文 / English / 日本語	
App Control	iOS / Android	

2.5mm

Over-The-Air (OTA) / MicroSD Card

ATLI X10 QUICK USER GUIDE

Digital Socket

Firmware Update

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference.
- (2) this device must accept any interference received, including interference that may cause undesired operation

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- \cdot Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- · Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction